




Step3




Step4




Step5




Step7




Step8



Step6




Step9



Nilo® N80s Theasel™

Assembly Instructions

Please retain this information for future reference




WARNING:

ADULT ASSEMBLY REQUIRED.


Product includes small parts with potentially hazardous sharp points and sharp edges in the unassembled state. Keep unassembled parts away from children.



Step 1



Step 2



DO THIS STEP ON A FLAT SURFACE SO THE EASEL WILL NOT WOBBLE.